

1: Start
About user manual

This user manual includes code system settings, function settings (lighting, keyboard type, and factory reset, etc.) and interface settings. If you need to change the function you need, scan the configuration according to the configuration code below. All bands (*) indicate the factory default value.

Reset default



FFFFFE

Recall Default



FFFF68

Read the Version Number

Interface mode initialization

Identify it as a USB keyboard type, scan the "USB keyboard" barcode.

In the environment where the application software requires the serial port, USB can be recognized as the USB COM type, and the USB COM type needs to be installed by the user



FFBFFE

USB Keyboard



FFBFFD

USB COM

Barcode on/off



FFFEFD

Turn on all barcodes

12. Data Matrix Code



66B791

*Enable